

Thank You

Thanks for purchasing an True Echo™ GWR200 guided wave radar level transmitter from us! We appreciate your business and your trust. Please take a moment to familiarize yourself with your sensor and this manual before installation. If you have any questions, at any time, don't hesitate to call us at 888-525-7300.

NOTE: Scan the QR code to the right to see the full user manual on your tablet or smartphone. Or visit <https://www.apgsensors.com/support> to find it on our website.



Table of Contents

- | | | |
|---------------------------|--|--|
| 1. Description | 5. Installation Guidelines | 8. True Echo™ GWR200 Default Application Setting |
| 2. How To Read Your Label | 6. Sensor and System Wiring | 9. General Care |
| 3. Warranty | 7. True Echo™ Software Installation and Communication Set Up | 10. Repair Information |
| 4. Dimensions | | |

1 Description

The True Echo™ GWR200 takes the mystery and frustration out of level measurement. With programmable 4-20 mA or RS-485 Modbus outputs, and innovative signal analysis, the True Echo™ can accurately measure solids, liquids, and slurries at depths up to 80 feet. NEMA 6 housing is standard, and 316 SS or PTFE-coated 316 SS probes operate in process temperatures from -40° to 398° F. Robust and reliable, the True Echo™ makes difficult level measurements easy.

2 How To Read Your Label

Each label comes with a full model number, a part number, and a serial number. The model number for the True Echo™ GWR200 will look something like this:

▲ SAMPLE: GWR200-4-W-N6-0-1-600-NN

The model number tells you exactly what you have. You can also call us with the model, part, or the serial number and we can help you.

You'll also find all hazardous certification information on the label.


3 Warranty

This product is covered by APG's warranty to be free from defects in material and workmanship under normal use and service of the product for 24 months. For a full explanation of our Warranty, please visit <https://www.apgsensors.com/about-us/terms-conditions>. Contact Technical Support to receive a Return Material Authorization before shipping your product back.

Scan the QR code below to read the full explanation of our Warranty on your tablet or smartphone.



4 Dimensions



True Echo™ Guided Wave Radar Installation Guide

For GWR200 Level Transmitter



Automation Products Group, Inc.
1025 W 1700 N Logan, UT 84321
www.apgsensors.com | phone: 888-525-7300 | email: sales@apgsensors.com

Part #122950-0034
Doc #9004827 Rev A

5 Installation Guidelines

The True Echo™ GWR200 should be installed in an area--indoors or outdoors--which meets the following conditions:

- Ambient temperature between -40° to 158° F (-40° to 70°C)
- Ample space for maintenance and inspection

Additional care must be taken to ensure:


- The probe is securely fastened to the sensor prior to installing the sensor on the tank or vessel.
- The sensor is mounted away from tank or vessel walls and inlets.
- The probe is free from obstructions such as inflows and agitators.
- The sensor is tightened by hand to avoid cross-threading.

***Important:** For user interface guide and sensor configuration see the full user manual.

Mounting your True Echo™ GWR200 is easy if you follow a few simple steps:

- Securely connect probe to sensor head prior to mounting sensor.
- Carefully feed probe through mounting hole
- Ensure that probe hangs free from obstructions
- Begin threading sensor NPT connection by hand
- Finish with wrench as necessary

6 Sensor and System Wiring Diagram



7 True Echo™ Software Installation and Communication Set Up

- Download True Echo™ Software and windows driver zipfile from <https://www.apgsensors.com/support>.
- Open the zip file.
- Choose "Install" from the options at the top of the zip file window.
- The software will create True Echo.exe which will run from a folder in your Start Menu titled "APG".
- Connect the True Echo™ Communication Tool to the Modbus Network Terminals shown in Section 6. Connect A on the True Echo™ Communication Tool to Comm A (TX A-) and B to Comm B (TX B+).
- Connect the USB side of the True Echo™ Communication Tool to a USB port on your PC.
- Double click the True Echo™ icon on your desktop or in your Start Menu.

8 True Echo™ GWR200 Default Application Setting

The default Application setting for the True Echo™ GWR200 is Level, which will work in a wide variety of settings. The True Echo™ GWR200 has additional Application settings that can be configured to meet your needs. The analog 4-20 mA output will automatically scale to the length of the probe.

All of the True Echo™ GWR200's adjustable settings are accessible through the True Echo™ Software, which is available at <https://www.apgsensors.com/support>.

9 General Care

Your level sensor is very low maintenance and will need little care as long as it was installed correctly. However, in general, you should periodically inspect your True Echo™ GWR200 sensor to ensure the sensor probe is free of any buildup that might impede the function of the sensor. If sediment or other foreign matter builds up on the probe, detection errors can occur.

If you need to remove the sensor, be sure to store it in a dry place at a temperature between -40° and 158° F.

10 Repair Information

If your True Echo™ GWR200 needs repair, contact us via email, phone, or online chat on our website. We will issue you an RMA number with instructions.

- Phone: 888-525-7300
- Email: sales@apgsensors.com
- Online chat at www.apgsensors.com